

Realview

User Manual Guide v1.5

English

ntroduction	3
Sign up & Sign in	3
Sign up	3
Sign in	6
Getting started	8
Tutorial	10
Navigation Bar	13
Dashboard	14
Alerts	17
Integrations	18
Reports	21
Step 1 – Select Devices	21
Step 2 – Select Type	22
Step 3 – Export	23
Profile	24
Settings	28
Support	29

Contents

Introduction

Realview NOW is an innovative web application which provides the user a complete overview of his/her security applications like **iAlert Plus**, **CM Car Alarm** and more. Thanks to the **Dashboard**, the user can get a detailed view of all the integrated devices latest locations with a pin or a heatmap, and also all of the latest alerts.

Sign up & Sign in

Sign up

By following this link <u>www.realviewnow.net</u> the user navigates to the **Realview NOW** homepage.



Realview NOW - Homepage

After clicking the login button the user needs to **create** an account.

To create an account, the user needs to click the "Sign up" button, fill all the necessary fields (Email, Password, Confirm Password) and also solve the Captcha to proceed.

Realview NOW – Sign up filled
Realview Welcome to Realview NOW
Create an account
- Email
example@email.com
password
Confirm Password
Vim not a robot
Sign up
Sign in instead
an uð _{is}

Rea	lview
Welcome to	Realview NOW
	2
Sign in to	your account
Email	
password	
I'm not a robot	
	Privacy - Terms
s	ign In
Sign up	Reset Password
Sign up	Reset Password

Realview NOW – Sign up form

After clicking the "Sign up" button that's mentioned in the image above, the user receives a verification code via Email. This verification code must be filled in the next field in order to continue with the account creation. Once again, the user solves the Captcha and clicks on the "Verify Code" button.





Realview NOW - Authenticator

Realview Welcome to Realview NOW

For the final step, the user needs to scan a QR code with his/her mobile device using an **Authenticator App**, like "Google Authenticator", "Authy" etc. and enter the code in the field to verify the TOTP (Timebased one-time password).

Realview NOW – Verification Code

Using an authenticator app like Google Authenticator is straightforward. Simply open the Google Authenticator app, log in to your Google account, and click on the "Add a Code" button. Then, scan the provided QR code to link your account. If the account is for a company, ensure that the company's device and email are used instead of personal contact information. This quick process enhances security with minimal effort.



Sign in

The procedure for the user to **Sign in**, is much simpler as he/she just needs to enter the email that was used for the **Sign up** and the password.



now.realviewnow.net says	
Please input the TOTP code.	
	OK Cancel
	OK Cancel

Realview NOW - TOTP code

After solving the Captcha and clicking the "Sign in" button, the user needs to fill the TOTP code from the **Authenticator App** that he/she previously used, and click "OK".

Getting started

After successfully signing in, the user needs to add a **Device/Receiver** by clicking the corresponding button to set up the **Dashboard**.

Realview			0
integrations	RealView Admin Connected Integrations:		
	Your devices		Add Device/Receiver
	# DEVICE ACCOUNT SERVICE STATUS	Enert	ALETT, MAP
		There are no records to display	
	© 2023 Almooond Ltd		Privacy Poli

Realview NOW - Add Device/Receiver

A window with all the available **Receiver Providers** appears, so the user can choose which one he/she wants to integrate.

Realview NO	W – Conne	ect a Receiver
Sel	ect provider to con	nect
•	Ø	()
iAlert Plus	iAlert Facility	CM Car Alarm
Realview* c.R.M. (psecurity	Realview	
RealView Admin	HR One	Camera Feed
	Μ	
	Gmail Alerts	
	Gmail Alerts	

After choosing a **Receiver**, the user must enter the appropriate "*PIN/Identifier*" and "*Password*" and click on the "*Authenticate*" button.

Authenticate with iAlertFacility	
PIN/IDENTIFIER	

Realview NOW – Authenticate a Receiver

ate rd"	Password	I				
te"	l'm	not a robot		reCAPTCHA Privacy - Terms		
			Authen	licate		
	Back					

Realview NOW – Finish Profile Setup

Welcome	to	RealviewNow!
---------	----	--------------

Finish your profile setup

You	r Name:
Yo	ur Name
User	name:
Us	ername
	Finish Profile setup

Finally, when the integration is done, a new window appears for the user to enter his/her **Name** and **Username** to finish the profile setup.

Tutorial

After finishing with the profile setup, the user is presented with a quick tutorial of the basics with demo data, starting with the **Dashboard Map**. The tutorial can be skipped by clicking "**X**" or continued by clicking "**Next**" on the tutorial card that appears.



Here is a quick overview of the tutorial.

	Realview NOW – Demo Alerts				
A	lerts OUI	alerts r latests alerts			
[DEI	MO DATA			
		Service	Device	Туре	Received
	>	iAlertPlus	223232	AUTOMATED ALERT	2022-11-03 15:15:22
	>	iAlertPlus	232321232	AUTOMATED ALERT	2022-11-03 14:59:18
	>	iAlertPlus	232111112	AUTOMATED ALERT	2022-11-03 10:01:05
			SEE MORE	ALERTS	
			SEE MORE		

After the **Demo Map** of the **Devices Latest Locations** and the **Latest Alerts** on the **Dashboard**, the tutorial shows the detailed **Alerts** and the **Devices** page both of which will be covered later on, in this manual.

When the user successfully finishes with the **Realview NOW** account, he/she can choose a preferred language, with the default one being English. By navigating to the **Profile** section from the **navigation bar** at the left of the screen. From there by clicking the "Edit" button of the Display Language, a menu appears with all the supported languages, with the current available being **English**, **German**, **Bulgarian** and **Greek**.

Your account overview	
Email:	Choose your preferred language
Username: Test Edit	Display Languages
Your Name:	
Example Edit	Update
Display Language:	
English Edit	
English Fair	

Realview NOW - Choose Language

Navigation Bar

The **Navigation bar** contains everything **Realview NOW** has to offer, helping the user to navigate through.

Dashboard

Provides information of the users' account, like the latest locations of his/her devices, the latest and the important alerts.

Alerts

Provides detailed information of all the **Receivers** alerts, like "Service", "Device", "Signal ID", "Alert Type" etc.

Integrations

Shows all the current connected integrations and lets the user add more or mark some as favorites.

Reports

Lets the user create a report of the devices he/she wants and export it as a ".csv" or ".pdf" file.

Profile

Displays the users' information with the ability to edit some basic profile info, upload a profile photo or choose a profile icon.

Settings

Allows the user to restart the tutorial, change password, request data and delete his/her account.

Support



uest data and

The user can communicate with us for a specific question or matter by sending a message or have his/her question answered by the **Frequently Asked Questions** tab.

Dashboard

As mentioned previously at the tutorial section, the **Dashboard** displays the users' account overview. After integrating a **Device/Receiver**, its latest location will be present in the "Devices Latest Locations" map window and the user can toggle a heatmap from the corresponding switch for each of the devices.

	Realview NOW – Devices Latest Location	
Devices Latest Locat	ions	Show Heatmap
No Devices Found		
ADD DEVICES		
NOD DEALCER		

The **Dashboard** also displays the latest alerts with detailed information, about the "Service" that gave the specific alert, the "Device" used, the "Type" of the alert and lastly the date and time that the alert was "Received". There is the option to also enable the auto-refresh toggle switch in the table, which refreshes both Latest & Important Alerts tables every 5 minutes. The **Dashboard Map** displays the alerts from the current page of the Important Alerts table. If there are no important alerts, it instead shows the alerts from the current page of the Latest from the current page from the current page of the latest from the current page fr

mpo	ortant Alerts	(7 days)			Enable Auto Refr	resh
	Service	Device	Туре	Received	Status	
>	iAlertFacility	21001	FIRE ALARM	11-03-2025 12:45:41	Not Seen	ę
>	iAlertFacility	21001	FIRE ALARM	11-03-2025 10:51:08	• Seen	Q T
>	iAlertFacility	21001	FIRE ALARM	11-03-2025 10:51:04	• Seen	٩
>	iAlertFacility	21001	FIRE ALARM	11-03-2025 10:37:37	• Seen	٩
>	iAlertFacility	21001	FIRE ALARM	11-03-2025 10:37:28	• Seen	٩
>	iAlertFacility	21001	FIRE ALARM	11-03-2025 10:36:20	• Seen	٩
>	iAlertFacility	21001	FIRE ALARM	11-03-2025 10:21:25	• Seen	۲
			Rows per page:	: 7 ▼ 1-7 of 34	I< <	> >
				7 💌 1-7 of 34		> >1
						4

Realview NOW – Important Alerts

In the Important Alerts Table, the user can control the auto-refresh of both tables, and also can manage the alerts visibility in the Dashboard Map with the pin icon for each alert. If a pin is red the specific alert is pinned and visible on the map with its own marker, if the pin is grey the specific alert is not visible. When a new alert appears, a notification sound will start playing to notify the user until the alert is marked as Seen, by clicking the arrow button. The notification sound can always be muted by the browser tab.

Note: Due to browsers policy the notification sound might not be audible if the user hasn't interacted with the webpage. This issue can be resolved by clicking, navigating or enabling the auto-refresh functionality.

Furthermore, the corresponding arrow button provides the user with the exact location of this alert when it was triggered, and based on the **Integration Device** used, in this example **iAlert Plus** an "Extra" voice message is received from the moment of the alert. Lastly, by clicking a marker in the map the user can see some extra details of the alert such as "Time received", "Alert Type" etc.



Alerts

The **Alerts** tab is specifically designed to store all of the users' alerts in detail, as mentioned before with the necessary fields and a status indication marking it as "Seen / Not Seen". Also, it allows the user to filter them by "Service" or by "Device Account" and customize the length of the current page by selecting the desired rows per page.

			Rediview NOW -	Aleris Idd		
					Ali Ale	rts View By Service
					Filter By Device Ar	ccount x
Service	device	Signal ID	Alert Type	Received	status	Мар
> iAlertPlus	107060756841	5758328	🙍 PANIC ALARM	2024-05-16 11:49:36	• Not Seen	Alert Details
					Rows per page: 10 ▼ 1-1 of 1	$\langle \langle \rangle \rangle$

By expanding each alert it marks it as "Seen", and besides the pinpoint location, the user also has the option to get a transcription of the voice message if there is one.

✓ iAlertPlus	107060756841 5927121 🖉 PANIC ALARM	09-08-2024 16:08:40	• Seen	Alert Details
ALERT TYPE:	S PANIC ALARM		Langadas	Ask
Integration Device:	iAlertPlus	Map Satellite Agios Athanasios Ay. Aθανάσιος	Οraiokastro Ωραιόκαστρο 2 Perifereiak	ADK A
Time received:	09-08-2024 16:08:40	Adendro Αδενδρο Platy	ndos võoc Thessaloniki	2+
Address	N/A	exandreia Πλατύ εξάνδρεια Χαλάστρα	Θεσσαλονίκη Kalamaria Mount Chortiati	s a w
Extra:	▶ ● 0:00 / 0:01 ◀ ●	Google Axios	Municipainy Asptarin; Καλαμαρία Keyboard abortouts Map da	Zagliveri ta ©2024., Terme, Report a map error
	lear a warea bases ▶ ● 0000000 ⊕●			

Integrations

The **Integrations** tab is vital for the functionality of **Realview NOW**, as it allows the user to add his/her **Devices/Receivers**, keeping them grouped in one place. It provides details for each device, such as "Device Account", "Service", a status indicator showing if the device is "Active / Not Active" and lastly the datetime of Expiration for the PIN.

You	ır devices				Add Device/Rece	eiver
#	DEVICE ACCOUNT	SERVICE	STATUS	EXPIRES	ALERTS MAP	
1	21001 😭	iAlertFacility	ACTIVE	None	Latest alerts	:
2	107060756841 🚖	iAlertPlus	• ACTIVE	2025-05-16 08:25:03	Latest alerts	:
					🚺 Latest alerts	

The user can also mark a device as favorite, by clicking the star icon. This will bring the selected alerts of the favorite device in the *Important Alerts* table in the **Dashboard**, making them easier to monitor.

	^
Select Important Alerts	
SELECT ALL MEDICAL ALARM FIRE ALARM TEST READ ORCODE	
Cancel	v
Cancel	

By clicking the 3 dots the user has two options:

- Share Device
- Remove Integration

Add user's email to share the device wit	
	n:
User Email	
Send share request	

() Share Device
TRemove Integration

If the user wants to share the device, he/she needs to provide the Email of the recipient's user and click on the "Send share request" button.

By clicking the "Latest Alerts" button, the user can get a heatmap for the latest alerts of each device, as well as the "ID", "Code" and the datetime of when the alert was received.



Reports

The **Reports** tab is responsible for creating a report in 3 simple steps:

Step 1 – Select Devices

The user can select one or multiple of his/her devices, by ticking the check box to include it in the report, and then click "Next".

	Realview NOW – C	reating a Report / Step 1
Selec	t the devices you want to include in th	e report:
	DEVICE ACCOUNT	SERVICE
	21001	iAlertFacility
	107060756841	iAlertPlus
	F	Rows per page: 10 ▼ 1-2 of 2 < < > >
	Back	Next
		Next

Step 2 - Select Type

In this step the user is presented with a list of the devices that were chosen, and the options to select the type of report that he/she wants to create for a specific date and time. After that, clicking "Next" will lead the user to the third and final step. The appearance and functionality of the date and time input fields may vary slightly based on the browser being used. This variation is due to browser-specific design and behavior, but the functionality remains consistent across all supported platforms.

DEVICE ACCOUNT:	SERVICE:
21001	iAlertFacility
elect the type of report you war	nt to create:
iAlertFacility	From:
 Attendance Image iAlert Facility Signals 	01/02/2025
Patrol Map	09:41 AM
	To:
	01 / 03 / 2025
	09:41 AM
Back	Next
Back	Next

Step 3 – Export

All that's left for the final step is to **download** the report. The report is saved as a ".csv" or ".pdf" file locally to the users' PC.

SERVICE	ALERT TYPE	DEVICE	DATETIME	SIGNAL ID
iAlertFacility	FIRE ALARM	21001	15-10-2024 19:28:20	6054928
iAlertFacility	PANIC ALARM	21001	15-10-2024 19:28:14	6054927
iAlertFacility	PANIC ALARM	21001	15-10-2024 17:28:54	6054847
iAlertFacility	PANIC ALARM	21001	15-10-2024 14:22:29	6054759
iAlertFacility	PANIC ALARM	21001	12-09-2024 12:18:17	5992158
	Download Report	XLS D	ownload Report PDF	
I				

Or if the selected report type is a Patrol Map, the user can download it by clicking the **Download Map** button.



Realview NOW – Creating a Report / Step 3b

Profile

The profile tab gives the user the ability to edit basic information of the account. It consists of three cards, the **Account Overview**, the **Profile Image** and the info **About** our company.

Rediview NOW - ACCOUNT Overview	Realview	NOW-	Account	Overview
---------------------------------	----------	------	---------	----------

Your account overview	
Email: (Verified) Username My Username Edit Your Name Edit Display Language: English	In fl edit Lan "Ed
Display Language: English [tax]	

In the Account Overview card, the user can edit the **Username**, **Name** and the **Display Language** by clicking the corresponding "Edit" button.

The user then types the new **Username** for example and clicks on "Update", to save the change.

username:	
My Username	
Update	

Realview NOW - Edit a field

The procedure of editing the Display Language is the same as the one the user did after finishing the account setup.

For the profile image, the user has an option to either upload a custom one from his/her device or PC, by clicking the "Choose File" button, finding and selecting the desired image and then clicking on the "Upload" button to save the change,



Or to choose one from the existing Animal Icons, by clicking the "Change" button and then selecting the desired one.



The **About** card has a detailed view of our **Privacy Policy**, as well as a contact Email. For more information about contacting us, please see the **Support** section.



Realview NOW – Profile Icon

Lastly, the **Profile** icon is always visible on the top right corner of each tab, and when clicked, a menu appears which gives the user the ability to navigate to the profile section or to "Log out" from the account.



Settings

The settings tab consists of four cards, **Onboarding Tutorial**, **Change Password**, **Request Data** and **Delete Account**.



Support

In the support tab the user can contact us about anything related to our company or services, by clicking the "Send Message" button,

Realview NOW – Send us a message	
Send us a message	
-	
SEND MESSAGE	

Which leads the user to a form where he/she can ask us a question after filling in all the necessary information and then clicking "Submit".

	Realview NOW – Contact us form	
Your Name *		
Phone Number	+30	
Your Email *		
Your Company *		
Subject *		
Your Question *		
	Submit	

Also, the user can take a look at the Frequently Asked Questions card before submitting the contact form, if a question is relevant to the users he/she can be provided with an answer directly by clicking the down arrow.

		Realview NOW – FAQ	
Fre	quently Asked Questions		
	What is the purpose of this app?		~
	What is the Dashboard?		~
	What are the Alerts?		\sim
	What are the Integrations?		\checkmark
	What are the Reports?		~

Thank you!